

Icon Automatic Series Handbook

Technical Specifications	
GTLS RATING	T25 or T100
CASE MATERIAL	316 stainless steel
CASE FINISH	Black PVD or brushed stainless steel
STRAP TYPE	Leather strap or stainless steel bracelet
CRYSTAL	Sapphire with triple anti-reflective coating
MOVEMENT TYPE	Automatic
MOVEMENT	Swiss made Sellita SW200-1
CROWN TYPE	Screw down
DIAL DIAMETER	38mm
CASE DIAMETER	44mm
CASE DEPTH	14.1mm
LUG WIDTH	22mm
FIXING TYPE	2 x 22mm spring bars (https://www.nitewatches.com/store/us/screws-pins/pack-of-two-22mm-spring-bars/)
WEIGHT	95g Fitted on leather strap 195g Fitted on steel bracelet
WATER RESISTANCE	100m


Setting the time and date

Unscrew the crown by turning anti-clockwise.

Position 1 is for winding the power. Wind the crown in a clockwise direction to re-power the watch.

Pull the crown gently into position 2 and turn the crown in a clockwise direction to the desired date.

Pull the crown gently into position 3 and turn the crown in a clockwise direction to move the time forward and anti-clockwise direction to move time back.



Strap fitting/options

The Icon models can be fitted with a leather strap, polymer strap, one-piece webbing or a stainless steel bracelet

With a 22mm lug width and 22mm spring bar fixing, straps are easily interchangeable using a forked spring bar tool. Many 22mm aftermarket straps are also compatible*

The Icon straps exclusively available through nitewatches.com can be found here:

<https://www.nitewatches.com/store/us/straps/icon>

The stainless-steel bracelet can be adjusted in length by adding or removing links and by also using the 3-micro adjustment on the buckle part of the strap.

Taking care of your automatic watch

Your automatic watch utilises a combination of intricate components working in unison to translate the motion of the wearer into stored energy to power the movement – truly connecting the timepiece with its owner.

Daily wear will ensure your automatic watch operates at optimum performance. Where required you may wish to consider the purchase of a watch winder.

We recommend that you have your automatic watch serviced every five years. Regular maintenance will ensure your watch remains clean and well lubricated, providing a lifetime of use.

**Nite Watches accept no responsibility with the sizing and fitting of any aftermarket straps.*

If you have any questions about the Icon Automatic series then please email us on sales@nitewatches.com.